

# NEW Molchem™ Cleaning System for Retail Checkstands and Belts

For best results and warranty compliance, follow the cleaning step system below and click the QR code to use.

**STEP 1: CLEAN** First remove any debris trapped between your Molchem™ Coated Belt and the checkstand conveyor strikeplate. Next generously spray the entire surface of your NEW Molchem™ Coated Belt with Molchem™ Checkstand and Belt Multi-Purpose Cleaner.

**STEP 2: WIPE** Thoroughly wipe your NEW Molchem™ Coated Belt with the Molchem™ Black Lint-Free Cloth until dust and grime are visibly removed. (In the case of extreme spills, remove as soon as possible with the Black Lint-Free Cloth. For stubborn stains remove with a Molchem™ Yellow Cleaning Pad).

**STEP 3: COAT** Finish by generously spraying the entire surface of your NEW Molchem™ Coated Belt with the BIOTREXX 247™ Antimicrobial Coating and wipe dry with a clean Molchem™ Yellow Lint-Free Cloth.

Complete all of the above daily or more frequently as needed and follow with the Molchem™ microfiber lint-free cloth care instructions.

\*It is recommended that the designated NEW Molchem™ products or their respective equivalents be used consistent with the NEW Molchem™ Checkstand and Belt Cleaning System for warranty compliance and provide lab certified compliance and protection.

To reorder Molchem™ products, please contact your checkstand supplier or call 1-800-729-2358 or on-line at [www.molchemclean.com](http://www.molchemclean.com)

*Thank you for your business!*

[www.molchemclean.com](http://www.molchemclean.com) | 2532 Waldorf Court NW | Grand Rapids, MI 49544 | 1-800-729-2358 | Developed and Fabricated in the U.S.A



## Recommended items:

- Molchem™ Checkstand and Belt Multi-Purpose Cleaner
- Molchem™ Checkstand and Belt Lint-Free Cloth
- Molchem™ Checkstand and Belt Cleaning Pad
- Molchem™ Checkstand and Belt BIOTREXX 247™ Antimicrobial Coating
- Molchem™ Extended Protection “Hours NOT Seconds™!” Hand Purifier & Antiseptic Shield



SAFETY PRECAUTIONS: Read all safety information on Molchem™ product labels before use.